



Fall 2017 - In This Issue:

[NEW OPTION FOR BOTTLE FILLING](#)

[PISTON INSERTER ENHANCEMENT](#)

[TIP OF THE QUARTER](#)

[WEBSITE UPDATE](#)



Fill Both Bottles and Syringes with One System

We are now offering the [Model 1050 syringe filler](#) with an add-on so customers can use the system to fill both syringes and small bottles. The add-on would allow a user to manually fill bottles up to 6 oz, making it well suited for use in low-volume production and laboratory settings. The system is recommended for use with fluids having a viscosity between 1 - 60,000 cP and can be paired with a number of different material reservoirs to accommodate different material package sizes. It is ideally suited for use with pharmaceutical, dental, and botanical materials. Call us today or [submit an inquiry](#) to find out more about this new option.

Model 3200 Piston Inserter Now Has Improved Chemical Resistance

We are proud to announce that we've enhanced the [Tridak Model 3200 piston inserter](#). The system's tooling is now made of Delrin, a polymer that is known for its high mechanical strength and rigidity, as well as its excellent resistance to solvents and other chemicals. When compared to other plastics like polycarbonate or ABS, Delrin parts provided much better chemical resistance, neither cracking nor softening when exposed to cleaning or accidental exposure.



Tip of the Quarter

To secure the fluid line connection on the [Tridak Model 2200](#), we recommend adding a clamp to the fluid line. This will make sure the connection is tight and prevent accidental disconnection and help prevent air or contaminants from making their way into the fluid line.



Our Website Has a New Look

The [tridak.com](#) website has a new look. Make sure to stop by the site to see all the changes.



Privacy Policy: We value your interest in Tridak filling systems by Dymax and hope you'll contact us when seeking solutions for your filling and packaging needs. Because of this, we consider your contact information and any other information you provide us as confidential. This means, most importantly, that we do not sell your contact information to anyone. Instead, your information is used by us solely to provide you with the information and assistance you have requested.

To continue receiving Tridak newsletters and announcements, please add newsletter@dymax.com to your address book.

[SafeUnsubscribe™ {recipient's email}](#)

[Forward email](#) | [About our service provider](#)

Sent by newsletter@dymax.com in collaboration with

Constant Contact 

Try it free today